

Doming Resin Instructions & Info

1:1 by Volume * *Equal Amounts of A & B* *

Doming Resin is used to encapsulate and protect pieces of artwork from paintings to coasters

Mix 1 part A to 1 Part B by volume, therefore (100ml of workable resin = 50ml A & 50ml B). Mix resin and hardener together, the resin will go cloudy - keep mixing for 3 – 4 minutes until resin goes back to clear **always mix by hand**. Keep the stirrer touching the bottom of the container unless scraping the sides while mixing to help to prevent bubbles forming in the Resin

Make sure all of the product has been mixed thoroughly, including scraping the sides of the mixing container. Pour resin and allow to cure.

Depth of Resin: Doming resin can be used to coat and can be poured to a maximum of 5mm.

Setting time of Resin: Working time: 1 ½ Hours
Initial Cure: 24 Hours
Full Cure: 3 Days



*Please note that the resin times are based on 25°c lab tested results and will vary on depth of pour and temperature.

Resin will not set below 10°c, and will take longer in a cooler environment, make sure on cooler days that the resin is in the sun or near heat, you can warm the bottles in hot tap water before pouring to allow the resin to heat up a bit